


# joovy®


## Nook™ 206X




© Joovy 2016 • 160502

USA: Joovy • 2919 Canton Street • Dallas, TX 75226 • Tel: (877) 456-5049 • Fax: (214) 761-1774 • Email: [customerservice@joovy.com](mailto:customerservice@joovy.com) • Website: [www.joovy.com](http://www.joovy.com)  
CANADA: Joovy Inc. • 4605 Trillium Blvd. Suite 107 • St. Laurent, QC H4T 2P2 • Tel: (514) 344-5049 • Email: [service@joovy.ca](mailto:service@joovy.ca)


1.1




B:




2.1




3.1




3.4




4.1




3.2




3.3




5.1




5.2




5.5



6.1



5.3



5.4

